

## Kompatibilitätsliste DÖRR / STO-FEN



### Canon

Canon 199-A		199 TW-199	
Canon 299	EZ	TW-UNI	Grün & Gold
Canon 300EZ	UNI		
Canon 300TL		300 TW-UNI	
Canon 380EX	C	TW-B	Grün & Gold
Canon 420EX	EX	TW-UNI	Grün & Gold
Canon 420EZ	B	TW-B	Grün & Gold
Canon 430EZ	B	TW-B	Grün & Gold
Canon 430EX	EW	TW-B	Grün & Gold
Canon 540EZ	EZ	TW-UNI	Grün & Gold
Canon 550EX	EZ	TW-UNI	Grün & Gold
Canon 580EX	EY	TW-UNI	Grün & Gold
Canon 580EX II	EY	TW-UNI	Grün & Gold
CanonMT-24EX	24X		

### Contax

Contax TLA280	C	TW-UNI	
Contax TLA360	C	TW-UNI	

### Hasselblad

Hasselblad Pro	CT45		Grün & Gold	Omni-Snoot
----------------	------	--	-------------	------------

### Metz

Metz 202, 402	MZ50	TW-UNI		
Metz 32 MZ-3	MZ2			
Metz 32 Z-1	MZ2			
Metz 32 Z-2	MZ2			
Metz 36AF	MZ3	TW-UNI	Grün & Gold	
Metz 40 AF-4N	PZ4	TW-UNI		
Metz 40 MZ1i	MZ40			
Metz 40 MZ2	C		Grün & Gold	
Metz 40 MZ3i	MZ40			
Metz 44AF	MZ2	TW-UNI		
Metz 48AF-1 C/N	MZ80	TW-UNI		
Metz 50 MZ5 Series	MZ50			
Metz 54 MZ3	C	TW-UNI	Grün & Gold	
Metz 54 MZ4	C	TW-UNI	Grün & Gold	
Metz 58 AF1	MZ80	TW-UNI		
Metz 70 MZ4	MZ70			
Metz 70 MZ5	MZ70			
Metz 76 MZ5OM	MZ70			
Metz CT/CL45 Series	CT45		Grün & Gold	Omni-Snoot
Metz CT60 Series	CT60		Grün & Gold	

### Minolta

Minolta 3500xi	MZ3	TW-UNI	Grün & Gold	
Minolta 3500HS	PZ8	TW-UNI		
Minolta 4000AF		4000 TW-UNI	Grün & Gold	Omni-Snoot
Minolta 5200i	C	TW-UNI	Grün & Gold	
Minolta 5400hs	C	TW-UNI	Grün & Gold	

Minolta 5400xi	C	TW-UNI	Grün & Gold
Minolta 5600hs	MZ6	TW-UNI	

## Nikon

Nikon SB-16	SB16	TW-UNI	Grün & Gold	Omni-Snoot
Nikon SB-24	C	TW-B	Grün & Gold	
Nikon SB-25	C	TW-UNI	Grün & Gold	
Nikon SB-26	C	TW-UNI	Grün & Gold	
Nikon SB-28	MZ3	TW-UNI	Grün & Gold	
Nikon SB-28DX	MZ3	TW-UNI	Grün & Gold	
Nikon SB-50DX	SB5	TW-UNI	Gold	
Nikon SB-80DX	SB5	TW-UNI	Gold	
Nikon SB-400	OM400			
Nikon SB-600		600 TW-UNI		
Nikon SB-800	SB5	TW-UNI	Grün & Gold	
Nikon SB-900		900 TW-UNI	Gold	

## Olympus

Olympus FL36		600 TW-UNI	Grün & Gold	
Olympus FL40	C	TW-UNI	Grün & Gold	
Olympus FL50	C	TW-UNI	Grün & Gold	
Olympus G40	C	TW-UNI	Grün & Gold	

## Panasonic

Panasonic PE36-S	B		Grün & Gold	
Panasonic 360E		600 TW-UNI	Grün & Gold	
Panasonic 500E	C	TW-UNI	Grün & Gold	

## Pentax

Pentax 300FTZ	UNI			
Pentax 330FTZ	MZ3		Grün & Gold	
Pentax AF220T	UNI			
Pentax AF360FGZ	PZ8	TW-UN		
Pentax AF500FTZ	C	TW-UNI	Grün & Gold	
Pentax AF540FGZ	MZ40			

## Sigma

Sigma 420	MZ3	TW-UNI	Grün & Gold	
Sigma 430	MZ3	TW-UNI	Grün & Gold	
Sigma 500 Series	C	TW-UNI	Grün & Gold	

## Soligor

Soligor MZ340AF	MZ3		Grün & Gold	
Soligor PZ400AFC		300 TW-UNI		

## Sony

Sony HVL-F1000	SB5		Gold	
Sony HVL-F32X	C	TW-UNI	Grün & Gold	
Sony HVL-FH1100	SB5		Gold	
Sony HVL-42 M	PZ8			
Sony HVL-42 AM	PZ8	TW-UNI		
Sony HVL-F36AM	PZ8	TW-UNI		
Sony HVL-F56AM	MZ6	TW-UNI		
Sony HVL-F58AM	HV58	TW-UNI	Gold	

## Vivitar

Vivitar 2500	C		Grün & Gold	
Vivitar 273	C	TW-UNI	Grün & Gold	
Vivitar 283	B	TW-B	Grün & Gold	SS-283
Vivitar 285	B	TW-285	Grün & Gold	SS-285/Snoot
Vivitar 3500	C		Grün & Gold	
Vivitar 3700		5600 TW-B	Grün & Gold	Omni-Snoot
Vivitar 4600 Std		5600 TW-B	Grün & Gold	Omni-Snoot
Vivitar 5600 Std		5600 TW-B	Grün & Gold	Omni-Snoot
Vivitar 5600 Zoom	B		Grün & Gold	Omni-Snoot
Vivitar 600N	EZ		Grün & Gold	
Vivitar 730AF	300T	TW-UNI		
Vivitar 836	MZ3	TW-UNI	Grün & Gold	
Vivitar 840AF	MZ3	TW-UNI	Grün & Gold	
Vivitar DF340Z		300 TW-UNI		
Vivitar DF400MZ	MZ3	TW-UNI	Grün & Gold	